










# Tools

| Description  | Purpose   | Part #                                      |
|--|---|---|
| <br>Thread Seal | To be used on threaded pipes and fittings to seal the joints.       | M6112<br>M6124<br>M6125<br>M6125PB<br>M6150 |
| <br>Putty      | Use as a seal for fixtures, sinks, tubs and more.                   | M6115<br>M6120                              |
| <br>Lubricant | For use on selected faucet components to keep them moving properly. | M6144<br>M6145                              |

| Description   | Purpose  | Part #                           |
|---|--|----------------------------------|
| <br>Pipe Cleaner     | Cleans pipes for leak proof solder joints.                   | M7710<br>M7720<br>M7770          |
| <br>Fitting Cleaner | Cleans fittings for leak proof solder joints.                | M7710<br>M7750<br>M7760<br>M7770 |
| <br>Tube Cutter    | Easily cuts various types of metal tubing to desired length. | M7530<br>M7540<br>M7562          |

| Description   | Purpose  | Part #                           |
|---|--|----------------------------------|
| <br>Seat Wrench        | Removes threaded faucet seats from faucet body.        | M7160<br>M7170                   |
| <br>Component Remover | Used to remove various fixture components.             | M3203<br>M7040<br>M7125<br>M7210 |
| <br>Basin Wrench     | Removal of under-the-counter faucet installation nuts. | M7010<br>M7011                   |